



Contact 1.888.398.8643 for assistance.
Do not return to place of purchase.

Assembly Instructions

Model No. S-1154, S-1156, S-1158, S-1301, S-1642

Hardware/Parts

Part	Description	Qty
1	Screen	1
2	Back Foot	2
3	Front Foot	2
A	Screw	6
B	Nut	4

Tools Required for Assembly (Not Included)

Phillips Head Screw Driver and Adjustable Wrench.

Steps

Step 1

Attach back feet to screen using 2 screws (A).

Step 2

Attach front feet to screen using 4 screws (A) and 4 nuts (B).

⚠ CAUTION: Keep this product clean by using a damp cloth. **DO NOT** use abrasive cleaners, as it will cause parts to tarnish.

