



Contact 1-888-398-8643 for assistance.  
Do not return to place of purchase.

## Assembly Instructions

### Model No. F-1730

#### Hardware/Parts

1	Base Handle	61-F1730-BSH
2	Yoke	61-F1730-YK
3	Poker	61-F1730-PK
4	Brush	61-F1730-BH
5	Base Rod	61-F1730-BSR
6	Shovel	61-F1730-SL
7	Log Lifter	61-F1730-LGL
8	Base	61-F1730-BS

A	Screw - M6x25	1 pc
---	---------------	------

#### Tools Required for Assembly (Not Included)

Phillips Head Screw Driver and Adjustable Wrench.

#### Steps


##### Step 1

Attach base to base rod. Attach yoke and base handle to base rod.

##### Step 2

Place poker, shovel, log lifter and brush on yoke.

**⚠ CAUTION: Keep this product clean by using a damp cloth. DO NOT use abrasive cleaners, as it will cause parts to tarnish.**





Composer le 1-888-398-8643 pour obtenir de l'aide.  
Ne pas retourner au point de vente.

## Mode d'assemblage Modèle n° F-1730

### Quincaillerie/Pièces

1	Poignée de base	61-F1730-BSH
2	Collier de support	61-F1730-YK
3	Tisonnier	61-F1730-PK
4	Balai	61-F1730-BH
5	Tige du socle	61-F1730-BSR
6	Pelle	61-F1730-SL
7	Pinces	61-F1730-LGL
8	Socle	61-F1730-BS
A	Vis - M6x25	1 pc

### Outils requis pour l'assemblage (non fournis)

Tournevis cruciforme phillips et clé à molette.

### Étapes

#### Étape 1

Fixez la tige du socle dans le socle. Fixez le collier de support et de la poignée de base à la tige du socle.

#### Étape 2

Placez le tisonnier, la pelle, le balai et la pince à bûches sur le collier de support.

**▲ ATTENTION : Veiller à ce que cet article demeure propre en le nettoyant à l'aide d'un chiffon humide. NE PAS utiliser de nettoyeurs abrasifs car ils risquent de ternir les pièces.**

