




# Console Table CF1124




# **PART LIST**




# HARDWARE LIST



Step 1. Insert cross bars (part G) to front shelf bar (part E) and back shelf bar (part F) using bolts (part #1) and allen wrench (part #2).



Step 2. Insert top front bar (part C), top back bar (part D) assembled unit (parts E, F & G) to left frame (part A) using bolts (part #1) and allen wrench (part #2).





Step 3. Attach right frame (part B) to assembled unit (parts C, D, E & F) using bolts (part #1) and allen wrench (part #2).


Note: Please fully tighten bolts at this time.

Step 4. Carefully turn unit upright. Insert top glass (part H) to top bars (parts C & D), and shelf glass (part I) to assembled unit (parts E, F & G).

Note: Safety strap kit (part #3) must be installed to prevent tipping, damage and/ or injury.

Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with floor in new location.

В




#3	A	В	С	D	E
			D8 x 1-1/2"	D10 x 1/2"	
Safety Strap Kit 1 SET	Wall Anchor 1 PC	Hook 2 PCS	Screw 1 PC	Bolt 1 PC	Safety Wall Strap 1 PC


### SAFETY WALL STRAP INSTALLATION

Important: Safety strap kit (part #3) must be installed to prevent tipping, damage and / or injury.

- 1) Insert bolt (D) through hook (B) and attach to predrilled hole in top back bar (part D) using a philips head screwdriver.
- 2) Drill 11/32" hole in the wall where this unit will be secured. The drilled hole will be at the same height as the hole in top back bar (part D) where hook (B) was attached. Tap wall anchor (A) into the drilled hole.
- 3) Insert screw (C) through hook (B) into the wall anchor (A) using a philips head screwdriver.
- 4) Insert safety wall strap (E) through both hooks (B) and tighten to secure.

Note: This item is not intended for clothing storage use.





#### **WARNING**

WARNING Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product NEVER allow children to stand, climb or hang on drawers, doors, or shelves. NEVER open more than one



- drawer at a time. Place heaviest items in the
  - west drawers. This is a permanent label.

Do not remove!